



ФАРКОГ.РФ

+7 (495) 669-38-36

NÁVOD NA MONTÁŽ:

- 1. Uvoľnite spodný plastový kryt.
- 2. Demontujte vlečné oko. Uvoľnite tlmič výfuku a hliníkový štit.
- 3. Vyrezte výrezy do spodného plastu a podľa obrázka - DETAIL.
- 4. Čažné zariadenie montujte podľa obrázka. Od spodku do nárazníka vložte rám A. Zl'ahka priskrutkujte konzoly B a C. Namontujte aj vlečné oko. K ľahko prichyteným konzolám priskrutkujte rám A. Skrutkové spoje dotiahnite momentom podľa tabuľky.
- 5. Elektroinštaláciu zapojte podľa návodu.
- 6. Skontrolujte správnosť pripojenia elektroinštalácie.
- 7. Prevedte spätnú montáž demontovaných častí.
- 8. Dotiahnite skrutky spojovacej gule (držiaka spojovacej gule) momentom podľa tabuľky.

Kód: T0605(A,I,C)

FITTING INSTRUCTIONS:

- 1. Loosen the bottom plastic cover.
- 2. Remove the towing eye. Loosen the exhaust silencer and aluminum shield.
- 3. Cut recesses in the lower mantle and ceiling bumper as shown - DETAIL.
- 4. Install the tow-bar as shown in the picture. From the bottom of the bumper insert frame A. Gently screw the brackets B and C. Install the towing eye. Easily attached to the frame brackets screw A. Torque all the screw connections as shown in the table.
- 5. Connect the electrical installation as described in the instructions for use.
- 6. Make sure the electrical installation is properly connected.
- 7. Reassemble any removed parts.
- 8. Tighten the screws of the linkage ball (holder of the linkage ball) to the torque shown in the table.

DÔLEŽITÉ UPOZORNENIA:

- V miestach stykových plôch sa musí odstrániť pružná ochrana karosérie vozidla.
- Vŕtané otvory treba ošetriť antikoróznou hmotou.
- Použite len dodaný spojovací materiál v predpisanej triede kvality.
- Elektrické zariadenie sa namontuje podľa podmienok prevádzky cestných vozidiel na pozemných komunikáciách.
- Údaj S o maximálnom zvislom zaťažení na gul'u je uvedený na výrobnom štítku ďažného zariadenia.
- Na ďažnom zariadení nie je možné nič upravovať ani meniť.
- Pred ukončením montáže je nutné prekontrolovať všetky spoje podľa tabuľky uťahovacích momentov!
- V prípade akýchkoľvek nejasností je nutné obrátiť sa na výrobcu ďažného zariadenia.
- Výrobca nenesie zodpovednosť za škody spôsobené nesprávnym použitím výrobku.

IMPORTANT ATTENTIONS:

- Remove insulating material on a car body in grips and joints of a coupling device with a car body.
- Put the anticorrosive substance on the drilled holes.
- Use supplied mechanical strength jointing material.
- Wiring of a coupling device must be up to a standard and car maker requirements.
- Statement S about the maximum vertical ball downtime is printed on the tow bar label.
- On the tow bar is no modification possible
- Check all the joints, look in the table of the spinning moments, before finishing the montage!
- Contact the tow bar marker with any questions.
- The manufacturer is not responsible for the damages caused by wrong using on the product.

Tabuľka uťahovacích momentov skrutkových spojov pevnosti 8.8 / Table of specified torque and hardenss settings 8.8

M6 - 9,5Nm, M8 - 23Nm, M10 - 46Nm, M10x1,25 - 49Nm, M12 - 79Nm, M12x1,25 - 87Nm, M12x1,5 - 83Nm, M14 - 125Nm, M16 - 195Nm