

(T107-A) Toyota RAV-4 2006-...	D (H)	S ()	T ()	C ()
	T107-A	6,0	75	1600
D = g* TC/T+C				
S -				
T -				
C -				

(T107-A) Toyota RAV-4 2006-...
1000
28248-89 «
37.001.096-93 «

1.		(T107-A) Toyota RAV-4 2006-...	1
	50		1
	18,4		1
			1

3.

nm (10,11) 12 1,25 45 (2).
(9) (10,11) 12 40 (1).
()

4.

1 (L/1)			
2 (54/2G)			
3 (31/3)			
4 (R/4)			
5 (58R/5)			
6 (54/6)			
7 (58L/7)			

.1 ()

1	12 40		6
2	12 1,25 45	+2	6
3	12 90		2
4	12		6
5	d.12		6
6			2
7	d.12		11
8			1
9			1
10			1
11			1

107-

